

ASSEMBLY INSTRUCTION
CP1712-C-1659



- 

A x8
Spec: $\phi 11.8 * \phi 10 * L11$
- 

B x8
Spec: 5/16*45
- 

C x8
Spec: $\phi 8 * \phi 14$
- 

D x1
Spec: 5#
- 

E x8
Spec:
- 

F x4
Spec:




FIG.
1




FIG.
2




FIG.
3






FIG.
4









DRAWER ASSEMBLY
CP1712-C-1659




DRAWER RENIVAL

ADJUSTABLE METHOD








1






2



1



2





**SERIOUS OR FATAL CRUSHING INJURIES CAN
OCCUR FROM FURNITURE AND TV TIP-OVER**

Never allow children to climb or play on furniture

For more information please visit:
www.structube.com/make-it-safe

**LE BASCULEMENT DE CE MEUBLE ET D'UN TÉLÉVISEUR
PEUT CAUSER DES BLESSURES GRAVES OU MORTELLES**

Ne jamais laisser les enfants grimper ou jouer sur ce meuble

Pour plus d'informations s'il vous plaît visitez:
www.structube.com/fr/en-toute-securite

**PUEDEN OCURRIR LESIONES SERIAS O INCLUSO FATALES COMO
CONSECUENCIA DE LA VOLCADURA DE MUEBLES Y DE TV**

Nunca permita que los niños se suban o jueguen en los muebles.

Para obtener más información, visite:
www.structube.com/us/que-sea-seguro