

ASSEMBLY INSTRUCTION

4153 - MLM611698 - 2599



A	B	C	D	E	F	G	H
							a x10 M6x22mm b x4 M6x35mm
1 PC	1 PC	2 PCS	1 PC	1 PC	1 PC	5 PCS	14 PCS
I	J	M	N				
1 PC	1 PC	1 PC	8 PCS				

FIG. 1




FIG. 2




FIG. 3

Assemble the armrest and back firstly.





FIG. 4

Assemble the armrest and seat cushion first.
After that attach the mechanism on the seat cushion.
Please notice the direction!


















A	B	C	D	E	F	G	H
							 a  x10 M6x22mm b  x4 M6x35mm
1 PC	1 PC	2 PCS	1 PC	1 PC	1 PC	5 PCS	14 PCS
I	J	M	N				
 P5							
1 PC	1 PC	1 PC	8 PCS				

FIG.
5




FIG.
6

